


center - pin 3  
shell - pin 8  
S/PDIF out


female rca



midi in


9  
nc  
5  
nc  
nc

nc = no connection



center - pin 2  
shell - pin 7  
S/PDIF in


female rca



midi out

6  
nc  
4  
1  
nc

nc = no connection



male connector end of breakout cable